

Work Order ID 65371

Thursday, January 13, 2011 1:29:37 PM



Page 1

Item ID: D350-567-025

Accept



Setup Start



Revision ID:

Stop



Item Name: Floor Window Installation, Large

Start Date: 1/13/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 1/14/2011 Req'd Qty: 1.00



Customer:

Reference:

Approvals:

Process Plan:

MF

Date: 11-01-13

Tooling:

Date:

Run Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/
Work Center ID

Operation
Description

Set Up/
Run Hours

Tool ID

Tool #

Plan
Code

Accept
Qty

Reject
Qty

Reject
Number

Insp.
Stamp

Draw Nbr

Revision Nbr

N/A

Rev D

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Copy bluefile and create labels & DT8439 per PPP D350-567-025 CHG002

CD 11/01/13

110

0.00



Packaging

Packaging

Memo

0.00

Packaging

Pick Packing Kit ***ENSURE DT 8439 TEMPLATE IS INCLUDED***

11/01/13

120

0.00



QC4- 100% Inspect kits for completeness

QC

Memo

0.00

Quality Control

Sullivan

(40)

Work Order ID 65371

Thursday, January 13, 2011 1:29:37 PM

Page 2

Item ID: D350-567-025

Accept

Setup Start

Revision ID:

Stop

Item Name: Floor Window Installation, Large

Start Date: 1/13/2011 Start Qty: 1.00

Required Date: 1/14/2011 Req'd Qty: 1.00

Cust Item ID:

Customer:

Reference:

Approvals:

Process Plan:

Date:

Tooling:

Date:

Run Start

QC:

Date:

SPC (Y/N):

Date:

Stop

Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run Hours

Tool ID

Tool #

Plan
CodeAccept
QtyReject
QtyReject
NumberInsp.
Stamp

130

0.00



Packaging

Packaging

Memo

0.00

Identify and pack for shipping as per PPP D350-567-

025 ☐ Location: 23 ☐ PPP Rev: C☐*****Ensure DT8439 template is included in
kit*****

140

0.00



QC

QC21- Final Inspection - Work Order Release

Memo

0.00

Quality Control

11/01/14
W 11/01/14

Picklist Print

Thursday, January 13, 2011 1:29:33 PM

Page 1

Work Order ID: 65371

Parent Item: D350-567-025

Parent Item Name: Floor Window Installation, Large







Start Date: 1/13/2011

Required Date: 1/14/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:B Added Cutting Template 05-12-14 JLM
IPP Rev:C 08-10-07 as per revD DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
5 D350-567-023  Replacement Window, Large	CHC7002	Manufactured	No			120	Each	0.0000	1	1			
										65372			
5 D350-567-031  Interior Floor Window (Sliding Door Compatible)	CHC7001	Manufactured	No			120	Each	0.0000	1	1			
										65373			
DT8439  template		Manufactured	No			120	Each	0.0000	1	1			
													

65372
65373
65374
11/01/13 ①

5.0 PARTS LIST

Qty -015	Qty -017	Qty -025	Qty -027	Qty -111	Qty -117	Part Number	Description
X						D350-567-015	FLOOR WINDOW INSTALLATION (SMALL)
	X					D350-567-017	FLOOR WINDOW INSTALLATION (SMALL)
		X				D350-567-025	FLOOR WINDOW INSTALLATION (LARGE)
			X			D350-567-027	FLOOR WINDOW INSTALLATION (LARGE)
				X		D350-567-111	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
					X	D350-567-117	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
1	1					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
		1	1			D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
				1	1	D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
	1		1	1		D350-567-115	INTERIOR FLOOR WINDOW KIT
1		1			1	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)

Qty -013	Qty -023	Qty -113	Qty -115	Qty -031	Part Number	Description
X					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
	X				D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
		X			D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
			X		D350-567-115	INTERIOR FLOOR WINDOW KIT
				X	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)
1					D2125	REPLACEMENT WINDOW, SMALL
	1				D2942	REPLACEMENT WINDOW, LARGE
		1			D3290-041	REPLACEMENT WINDOW ASSEMBLY, EXTRA LARGE
1					D2126-0600	SEAL
	1				D2463-0750	NEOPRENE SEAL
		1			D2463-0860	NEOPRENE SEAL
	9	12			2600-6	1/4 TURN FASTENER
	9	12			2600-LW	WASHER
	9	12			212-12	RECEPTACLE
	22	21			AN526C832R9	SCREW (OR AN526C832-9, OR MS51957-126)
	44	42			AN960JD8	WASHER
	22	21			MS21042L08	NUT (OR MS21042-08)
	18	24			MS20426AD3-5	RIVET
2 SQ. YD	2 SQ. YD	2 SQ. YD			N/A	9.7oz 7781 'S' GLASS UNIVERSAL WEAVE
				1	D2463-0450	NEOPRENE SEAL
				1	D3210-1	DOUBLER
				1	D3211-1	BRACKET
				1	D3212-1	FLOOR WINDOW
				1	D3213-041	DOOR ASSEMBLY
			1		D3293-1	DOUBLER
			1		D3294-1	BRACKET
			1		D3295-041	FLOOR WINDOW
			1		D3296-041	DOOR ASSEMBLY
			1		D2463-0530	NEOPRENE SEAL
			9	8	AN526C632R12	SCREW (OR AN526C632-12, OR MS51957-32)
			9	8	AN960JD6	WASHER
			9	8	MS21042L06	NUT (OR MS21042-06)
			2	40	MS20470AD4-5	RIVET
			115	90	MS20470AD4-6	RIVET
			15	20	MS20470AD4-7	RIVET

• COPYRIGHT © 2000 BY DART AEROSPACE LTD. •
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED
OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: D
Date: 08.07.08